


PAIRING FOB AND CUBE

INITIATING PAIRING MODE

- Quickly tap a magnet on the LED on the front of the iQ cube 3 times, ensuring the LED turns from green to orange each time. The LED will flash faster, indicating that it is now in pairing mode.



PAIRING THE FOB

- Press and hold the 1st and 3rd buttons on the keyfob remote simultaneously to pair it with the iQ cube. The iQ cube LED will flash rapidly, indicating that the devices are successfully paired. Repeat the process to pair another keyfob to the iQ cube.



CLEARING ALL FOB PAIRINGS

RESETTING THE CUBE (ONLY IF NEEDED)

- To clear past pairings and reset the iQ cube, quickly tap the magnet on the LED 6 times, ensuring the LED turns orange each time. The LED will rapidly flash blue, indicating that the iQ cube memory is erased.

